


The Lotte Wrap




tales^{of}
threads




Video: 0:00

Welcome to our Lotte Wrap Sewing Tutorial! Let's get started.



Video: 0:04

Before cutting your fabric, fold it in half lengthwise so that the selvages, the finished edges of the fabric, align. Lay the pattern pieces on the fabric like you see on this image and carefully cut around them.




Video: 0:19

To transform the top into a dress, extend the length of the bottom front and back pieces according to the measurements specified in the pattern.



Video: 0:28

Transfer the notches on the front top pieces onto the fabric by making small nicks about 2-3mm deep



Video: 0:37

Now, we also cut the interfacing. Before cutting, fold the interfacing in half lengthwise so that the selvages, the finished edges of the interfacing, align. Lay the pattern pieces on the fabric like you see on this image and carefully cut around them.



Video: 0:52

Let's move on to crafting the straps. Take one short strap and iron both long edges 1cm inward, toward the fabric's wrong side. Iron one short end 1cm inward, again toward the wrong side.



Video: 1:05

Fold the strap in half lengthwise and iron it.




Video: 1:09

Unfold the strap at the short end. Then, open the right long side.



Video: 1:13

Next, fold the strap back in half.



Video: 1:15

Tuck the right long side into the fold created on the left long side.



Video: 1:20

Iron so that it stays in place.



Video: 1:22

Secure the straps by sewing along the long edge and then the folded short edge, maintaining a 3mm distance from the edge.



Video: 1:30

Prepare the unfinished edges of both straps. Measure and mark 1cm from the edge along the long side you've stitched. From this marked point, draw a diagonal line to the opposite tip on the other long side of the strap. Cut along this diagonal line.



Video: 1:45

We are moving on to the top. Your interfusing pieces have a soft side and an adhesive side. Attach the interfacing to the front neckline of the tops by placing the adhesive side against the wrong side of the fabric, then iron to secure.



Video: 2:01

Fold the neckline inward by 1cm, then fold it another cm inward, and iron to create a clean edge.



Video: 2:10

Locate the two cuts at the bottom of the front pieces. Align these cuts by folding them, ensuring the right sides of the fabric are facing each other. Secure this alignment by inserting a pin at the cuts.



Video: 2:21

Measure 12cm from the bottom of the top along the newly created fold and mark this point.



Video: 2:27

Draw a diagonal line connecting the mark with the pin. Stitch along the line you've drawn, remembering to backstitch at both the start and finish.



Video: 2:37

Press the darts you just created towards the sides of the top using an iron.



Video: 2:42

Take the right front piece. Trim the excess fabric from the bottom edge.



Video: 2:46

Unfold the neckline by 1cm and mark 2cm from the bottom edge.



Video: 2:53

Position the short strap under the fold at the neckline, aligning the stitched edge with the marking you made.



Video: 2:59

Fold the strap over the folded neckline to the left side, ensuring it aligns with the bottom of the top, and secure it with a pin.



Video: 3:07

Stitch along the folded-over neckline, 8 mm from the edge, leaving 2 mm of the hem on the other side.



Video: 3:15

Repeat the same process with the long strap on the left side.



Video: 3:20

Secure the straps with an extra stitch near the edge of the neckline.



Video: 3:25

Attach the interfacing to the back facing by placing the adhesive side against the wrong side of the facing fabric, then iron to secure.



Video: 3:35

Finish the outer edge of the back facing pieces with an overlock stitch to prevent fraying.



Video: 3:39

Take the front pieces and lay them over the back piece, ensuring the right sides of the fabrics are facing each other.



Video: 3:48

Allow the back piece to extend 1cm beyond both sides of the neckline.



Video: 3:56

Pin along the shoulders. Stitch the shoulders together with a 1cm seam allowance



Video: 3:58

Place the back facing on top of the top, ensuring that the right side of the facing is against the wrong side of the top. Align the shoulder seams and neckline, then pin and sew them together using a 1 cm seam allowance.



Video: 4:13

Finish the shoulder seams with an overlock stitch.



Video: 4:15

Trim the excess fabric at the neckline, leaving a seam allowance of a few millimeters.



Video: 4:22

Fold the facing inward, press it with an iron, and stitch it in place using a 8mm seam allowance.



Video: 4:32

Overlock the sides of the front and back pieces separately for a clean edge finish. Then, place the pieces on top of each other with the right sides of the fabric facing each other. Secure the sides together with pins.



Video: 4:49

Stitch together the left sides with a 1cm seam allowance.



Video: 4:51

On the right side, from the bottom, measure up 1.5 cm and place a mark. Then, from that mark, measure another 3 cm upwards and place a second mark.



Video: 5:07

Stitch the sides together using a 1cm seam allowance, stopping at the first mark. Resume stitching after the second mark, ensuring you leave a gap between the two marks.



Video: 5:13

Press both seams open with an iron.



Video: 5:17

Stitch around the gap to secure it.



Video: 5:20

Moving on to the bottom section. Align the front pieces with the back pieces by matching their diagonal sides, ensuring the right sides of the fabric face each other. Sew along both sides using a 1cm seam allowance and finish with an overlock stitch.



Video: 5:38

Press both seams toward the back.



Video: 5:42

Sew a continuous stitch along the bottom's straight sides and bottom edge, 8mm from the edge.



Video: 5:52

Fold the straight side over by 1cm and press it with an iron, using the 8 mm stitch line as a guide for evenness. Fold it over again by the same amount, pressing as you go.



Video: 6:05

Repeat this process along the bottom edge and the other straight side.




Video: 6:12

At the bottom corners, unfold the second fold on each side. Draw a line where the two seam allowances intersect.



Video: 6:21

Fold the tip in half, right sides of the fabric together.



Video: 6:26

Sew along the line you marked.



Video: 6:30

Cut off the tip, leaving an 3 mm seam allowance.



Video: 6:33

Turn your seam allowance towards the inside of the double folded hem, turn out the corner and give it a final press with your iron.



Video: 6:45

Now we are going to attach the top to the skirt. Place the top over the skirt, ensuring that the bottom edge of the top aligns with the top edge of the skirt. The right sides of both pieces should face each other.



Video: 6:53

Align the sides seams.




Video: 6:59

Align the side edges of the top with the first crease on the bottom (created by ironing), ensuring the bottom extends 2cm beyond the top.



Video: 7:09

Ensure your darts are still folded towards the back.



Video: 7:15

Sew with a 1cm seam allowance, then finish with an overlock stitch for neatness.



Video: 7:20

Neatly fold the overlock stitch downwards.



Video: 7:24

Next, carefully align the creases on the skirt, ensuring they are precisely in place.



Video: 7:34

Pin to secure the fabric in place. Then, stitch the sides and bottom edges, 8mm from the edge.



Video: 7:41

You are done! Check out our other videos for your sleeves of choice.